

SANUPS

ON LINE UPS

A11J

LCD Panel

Operating Manual

SANYO DENKI

Introduction


Thank you for choosing the **SANUPS A11J**.

SAVE THESE INSTRUCTIONS

This manual describes the functions and setting operations of the LCD panel menus. To operate correctly, read this manual when setting or changing the LCD panel menus of the UPS. Please be sure to also read the ***A11J Instruction Manual*** for details about UPS installation and operation. Store this manual together with the ***A11J Instruction Manual*** in a safe place for convenient reference.


UPS is an abbreviation for Uninterruptible Power Supply.

Table of Contents

§1. Identifying LCD Panel.....	1
§1.1 Names of LCD Panel Parts.....	1
§1.2 Functions of Home Menus.....	2
§1.3 How to Operate LCD Panel.....	3
§2. Viewing UPS Information.....	4
§2.1 Viewing UPS Operation Status.....	4
§2.2 Viewing UPS Measurements.....	5
§3. Setting UPS.....	6
§3.1 Setting Voltage.....	8
§3.2 Setting Synchronous Frequency Tracking Range.....	9
§3.3 Setting Frequency.....	10
§3.4 Setting Voltage for Measurement Display.....	11
§3.5 Setting PC Interface.....	12
§3.6 Setting Baud Rate.....	13
§3.7 Setting UPS Operation Upon Power Recovery.....	14
§3.8 Setting Buzzer Condition.....	15
§3.9 Setting UPS Shutdown Operation.....	16
§3.10 Setting Overload Recovery Operation.....	17
§3.11 Setting UPS Operation at  OFF.....	18
§3.12 Setting Low Battery Voltage Warning Timing.....	19
§3.13 Setting Battery Test Time.....	20
§3.14 Setting Battery Test Schedule.....	21
§3.15 Setting Backup Time During Power Outage.....	22
§3.16 Setting RING Signal.....	23
§3.17 Setting Adjustment for Output Voltage.....	24
§3.18 Setting Clock.....	25
§3.19 Setting Number of UPS Units in Parallel Connection.....	26
§3.20 Setting Operation System.....	27
§3.21 Setting Input Phase.....	28
§3.22 Resetting Values of Settings.....	29
§3.23 Restarting UPS.....	30
§4. Operating UPS.....	31
§4.1 Running Battery Test.....	32
§4.2 Reading Battery Test Result.....	34
§4.3 Starting or Stopping UPS.....	35
§4.4 Switching to Bypass Operation.....	36
§5. Maintenance Menu (For Service Technician).....	37
§6. Menu List.....	38
§7. Status Description.....	41
§8. Notes on UPS Measurements Information.....	42

§1. Identifying LCD Panel


§1.1 Names of LCD Panel Parts



No.	Name	Label	Color	Function	
①	Input LED	INPUT	Green	Lights	When input power is normal
				Blinks	When input power is abnormal
②	Backup LED	BACKUP	Green	Lights	When the battery is operating
③	Warning LED	WARNING	Red	Lights	Caution/warning, malfunction, or end of battery discharge
④	Output LED	OUTPUT	Green	Lights	When supplying power by inverter operation
				Blinks	When supplying power by bypass operation
⑤	LCD screen	—	—	Displays UPS status information, measurement values, maintenance support information, various setting values, operation, etc.	
⑥	ON/OFF button	—	—	Starts and stops inverter operation	
⑦	SELECT key	SELECT	—	Select and accept LCD display item or content	
⑧	ITEM key	ITEM	—	Switches LCD display item or content	
⑨	BACK key	BACK	—	Cancel the selection and returns to previous LCD display (menu) level	
⑩	HOME Key	BUZZER STOP HOME	—	Return the LCD display (menu) level to the home menu When the buzzer is sounding, stops the buzzer	

About LCD panel

- About indication in LED illustration
LEDs are indicated in the form of “Green INPUT”, “Red WARNING”, etc.
- About LCD panel cover operation
When using the ON/OFF button or keys:
Slide down the cover.
After the operation, return the cover to its original position.
This will prevent accidental operation.




§1.2 Functions of Home Menus

The LCD panel provides five home menus. Each home menu has its own setting groups and settings. For details on each of the home menu and how to change settings, read the respective pages of the home menu. §6. "Menu List" summaries all menus and settings.

Home menu	Function	Description
<p>STATUS</p> <p>Read page 4.</p>	<p>Status/state display</p> <p>Displays UPS status.</p>	<p>Displayed status items:</p> <ul style="list-style-type: none"> Operation mode, Input power, output power, battery state, Internal error, load factor etc.
<p>MEASUREMENT</p> <p>Read page 5.</p>	<p>Measurements/measurements display</p> <p>Displays UPS measurements.</p>	<p>Displayed measurement items:</p> <ul style="list-style-type: none"> Input power (voltage, frequency) Output power (voltage, current, load factor, frequency) Battery (voltage, charging rate, operating duration, battery life, number of outages) Charging power (voltage, current) Temperature (around device, battery temperature)
<p>SETTING</p> <p>Read pages 8 to 29.</p>	<p>Setting/setting</p> <p>Change various UPS settings.</p>	<p>Settings:</p> <ul style="list-style-type: none"> Input/output: voltage, frequency, display Interface: interface, baud rate Operation: startup condition, buzzer sound, off operation, overload operation, output off operation Battery: low battery voltage warning timing, battery test time, test schedule Function: operating time during outage, ring signal, output voltage adjustment System: time, number of connected units, operation system, input phases
<p>CONTROL</p> <p>Read pages 31 to 36.</p>	<p>Control/operation</p> <p>Operate the UPS.</p>	<p>Operation items:</p> <ul style="list-style-type: none"> Battery test, test result display Turn on/off UPS Switch to bypass operation
<p>MAINTENANCE</p> <p>Maintenance menu (for service technician)</p>	<p>Maintenance/maintenance</p> <p>Menu for service technician. Display or change maintenance settings.</p> <p>Do not use this home menu if you are not a service technician. For details, refer to the maintenance manual for service technician.</p>	<p>Displayed items:</p> <ul style="list-style-type: none"> Malfunction history, operation history, battery information, Operating state and measurements of each unit <p>Settings:</p> <ul style="list-style-type: none"> Battery backup time, battery life

§1.3 How to Operate LCD Panel


① Slide down the cover, and then press to display the LCD screen.




Note

- If you press while the UPS's buzzer is beeping, the buzzer stops. If a single press fails to stop the buzzer, keep pressing repeatedly until the buzzer stops. The menu will not appear on the LCD screen if you press while the buzzer is beeping.
- If you do not operate the LCD screen for over 10 minutes, the panel light goes off. In about 30 seconds later, the UPS mode and input/output power measurement information appears randomly as screen saver. Pressing any key displays the "STATUS" of home menu.
- The actual text that appears on the LCD screen may be different from the text and position described in the operating manual.

② Press to change screen.



➔ ③ Press to accept the selected item.



Repeat steps ② and ③ to display or set an item.


Example: From the "SETTING" screen, press . Then, from the "SETTING" menu, select the interface setting.

The menu structure is shown below and contains several levels.

Press to move to the next level or press to return to the previous level.

Each level has several items. Pressing repeatedly cycles through the items.

When an item appears on the screen, pressing accepts the item and then moves to the next level. The number of levels and items are different depending on the menu, but the procedure is the same.



④ Press to return to the home menu, and then return the cover to its original position.



For details on menu contents and screen display, read their respective pages.

§2. Viewing UPS Information

§2.1 Viewing UPS Operation Status

You can view the current operation status of the UPS system.

- ① Press **(HOME)** to display the LCD screen.
- ② Make sure "STATUS" appears on the screen.
- ③ Press **(SELECT)** to display the UPS status.



• Upper line: UPS mode
 • Lower line: Status information such as measurements, warning, and malfunction.

If there are multiple statuses, the lower line automatically scrolls to display them.

Tip

*1. Pressing **(ITEM)** repeatedly cycles through the displayed items. If you miss a desired item, just keep on pressing until you see it again.

*2. To return to the previous level, press **(BACK)**.

*3. For details on the displayed contents, consult your supplier or SANYO DENKI. Also, if device error or malfunction information appears, contact your supplier or SANYO DENKI.

According to the state of the UPS, the LCD screen displays its UPS mode in the upper line and its status in the lower line. For details on the displayed status and how to handle it, see §7. "Status Description".

UPS mode (upper line)		Status (lower line)			
Display	Description	Display	Description	Display	Description
STANDBY	Standby	Output Not Sync	Asynchronous operation	Batt Life End	End of battery life
ONLINE	Online	Input Freq Err	Input frequency error	Batt Life Warn	Battery life end warning
BYPASS	During bypass operation	Input Vol Hi	High input voltage	Batt Vol Error	Battery voltage error
BATTERY	During battery operation.	Input Vol Low	Low input voltage	Batt Vol End	End of battery discharge
BATT TEST	During battery testing	Input Error	Input error	Batt Vol Low	Low battery voltage
SYS FAILURE	During system malfunction	INV Vol Hi	High inverter voltage (serious malfunction)	CHG Error	Charger error (serious malfunction)
		INV Vol Low	Low inverter voltage (serious malfunction)	CONV Error	Converter error (serious malfunction)
		INV Vol Error	Inverter voltage detection circuit error (serious malfunction)	BF Circuit Error	Back feed prevention circuit error (serious malfunction)
		Output Stop (HV)	Bypass output stopped (excessive voltage)	FIN Temp Error	Fin temperature error (serious malfunction)
		Over Load	Overload	DSP Error	Controller error (serious malfunction)
		Vo= V Fo= Hz	Output voltage, output frequency	BUS Error	DC voltage error (serious malfunction)
		Vi= V Fi= Hz	Input voltage, input frequency	AUX2 Error	Auxiliary power error (minor malfunction)
		LF= % CHG= % *	Load factor %, Charging rate %	Total Unit# Err	Total number of units error (serious malfunction)
		LF= % Tim= m *	Load factor %, Charging duration minutes	LCD Error	LCD panel error
		Byp Fuse Error	Bypass fuse error	Minor Error	Minor malfunction
		Bypass SW ON	Bypass switch ON	Fatal Error	Serious malfunction
		Req To Restart	Restart is necessary	FT Disabled	Redundant operation not allowed
		Remote	Battery test by remote operation in progress	Check Unit Error	Device error exists and checking is required
		Remote OFF	Operation stops due to remote OFF	EPO ON	Operation stopping due to EPO


* Refer to §8 "Notes on UPS Measurements Information."

- ④ Press **(HOME)** to return to the home menu.

§2.2 Viewing UPS Measurements

You can view various UPS measurements.
The displayed measurements refer to numbers about the UPS system.


- ① Press **HOME** to display the LCD screen.
- ② Press **ITEM** to change the home menu to the one shown below.
- ③ Press **SELECT** to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
"Home menu" → "Measurement setting" → "Measurements"
- ⑤ Press **ITEM** to select a measurement to view.



Tip

- *1. Pressing **ITEM** repeatedly cycles through the displayed items. Therefore, if you miss a desired item, just keep on pressing until you see it again.
- *2. To return to the previous level, press **BACK**.

Example: Viewing UPS input voltage



Measurement settings	Measurements	
	Measurements displayed	Description
INPUT (input measurements)	Vin = V	Input voltage
	Fin = Hz	Input frequency
OUTPUT (output measurements)	Vout = V	Output voltage
	Iout = A	Output current
	LF = % *	Load factor
	Watt = kW	Output power
	Fout = Hz	Output frequency
BATTERY (battery measurements)	Vbatt = V	Battery voltage
	ChgRate = % *	Battery charging rate
	RunTm = Min. *	Battery retention time
	Power Failure Times	Number of outages
	Battery Life Years	Battery life
	Backup OPE. Time Sec.	Accumulated time on battery operation
CHARGER (charger measurements)	Vchg = V	Charger voltage
	Ichg = A	Charger current
TEMPERATURE (temperature measurements)	T-Amb = °C	Ambient temperature

* Refer to §8 "Notes on UPS Measurements Information."


- ⑥ Press **HOME** to return to the home menu.

§3. Setting UPS

The SETTING menu contains 7 settings groups. The “*” in the “Default setting” column indicates factory defaults. Change the settings to suit your operating environment or usage. For details on how to change the settings, read sections §3.1 to §3.22. Once you change the value of a setting, we recommend that you place a check mark in the “Current setting” column.

List of settings

Home menu: SETTING

Settings group	Settings		Values		Default setting	Current setting	Ref item	Ref page	
	Display	Description	Display	Description					
SET IN/OUT (Input/Output Setting)	Voltage	Voltage ★	Set UPS voltage. Output voltage and input voltage are the same.	200V	Output voltage 200V	*		3.1	8
				220V	Output voltage 220V				
				230V	Output voltage 230V				
				240V	Output voltage 240V				
FREQ Range	Synchronous frequency tracking range ★	Set the range (%) at which the output frequency tracks the input frequency.	1%	±1%	*		3.2	9	
			3%	±3%					
			5%	±5%					
Frequency	Output frequency ★	Set output frequency.	Auto	Automatic selection	*		3.3	10	
			50Hz	Fixed at 50Hz					
			60Hz	Fixed at 60Hz					
Display	Voltage current display	Set input/output voltage and current for display in measurements display etc.	200V/200V (S) *3	200V/200V(S)	*2		3.4	11	
			200V/100V	200V/100V					
			100V/200V	100V/200V					
			100V/100V	100V/100V					
SET I/F (Interface Setting)	Interface	Interface	Set interface for using PC interface connector.	Standalone	Standalone			3.5	12
				WS	Workstation	*			
				Terminal *1	Terminal				
Baud Rate	Baud rate	Set baud rate for connection with PC, LAN card, or workstation.	9600	9600bps	*		3.6	13	
			4800	4800bps					
			2400	2400bps					
SET OPERATION (Operation Setting)	Start Condition	Specify power recovery operation.	Set UPS operation to perform when utility power recovers, after UPS stops due to end of battery discharge in power outage.	Auto	Auto start	*		3.7	14
				Any Condition	Always start				
				STOP	Stop				
				BATT>30%	Start when charging rate reaches 30%				
				BATT>50%	Start when charging rate reaches 50%				
	BATT>80%	Start when charging rate reaches 80%							
BUZZER	Buzzer sound	Set when the buzzer should beep.	ALL	All	*		3.8	15	
			Group #1	Group 1					
			Group #2	Group 2					
OFF Operation	Operation of OFF	Set how to turn off  on the operation panel of the main unit to stop the UPS.	1 Sec.	Turn off when pressed for 1 second	*		3.9	16	
			3 Sec.	Turn off when pressed for 3 seconds					
OVERLOAD	Operation for overload	Set what to do after power supply switches to bypass due to overload.	Unique	Turn off by special operation			3.10	17	
			Auto Ret BYP	Automatic recovery from bypass					
			Stay on BYP	Bypass power supply during overload	*				
Output @OFF	Power supply during OFF ★	Set output's power supply state when UPS stops.	Output OFF *1	Stop output			3.11	18	
			OFF	Stop output	*				
SET BATTERY (Battery Setting)	BATLV Timing	BATLV timing	Set when to issue low battery voltage warning.	Voltage	When battery voltage threshold detected	*		3.12	19
				2 Min.	When 2 minutes left in battery capacity				
				3 Min.	When 3 minutes left in battery capacity				
				5 Min.	When 5 minutes left in battery capacity				
				10 Min.	When 10 minutes left in battery capacity				
	BATT TST Length	Battery test time	Set duration to perform battery test.	2 Min	Run for 2 minutes	*		3.13	20
				5 Min.	Run for 5 minutes				
				10 Min.	Run for 10 minutes				
				20 Min.	Run for 20 minutes				
	BATT TST Period	Battery test schedule	Set interval (number of days) to run battery test automatically.	180 days	Automatically every 180 days	*		3.14	21
90 days				Automatically every 90 days					
30 days				Automatically every 30 days					
None				No automatic testing					

Settings group	Settings			Values		Default setting	Current setting	Ref item	Ref page			
	Display	Description		Display	Description							
SET FUNCTION (Function Setting)	RUN TIM @PF	Operating period during outage	Set the time from when UPS starts backup to when it stops output.	BATT END	Until end of battery discharge	*						
				10 Sec.	Stop output after 10 seconds							
				30 Sec.	Stop output after 30 seconds							
				1 Min.	Stop output after 1 minute				3.15	22		
				3 Min.	Stop output after 3 minutes							
				5 Min.	Stop output after 5 minutes							
	10 Min.	Stop output after 10 minutes										
	RING Output	RING operation	Set whether to output RING signal during UPS startup.	Output	Output	*			3.16	23		
	Out Vol Adj.	Output voltage adjustment	Set value adjustment for rated voltage set in 3.1. Each increment of adjustment is about 1V	-3	Minus 3 increments							
				-2	Minus 2 increments							
-1				Minus 1 increment								
0				No adjustment	*			3.17	24			
+1				Plus 1 increment								
+2				Plus 2 increments								
+3				Plus 3 increments								
SET SYSTEM (System Setting)	DATE/TIME	Date/Time	Set date and time for UPS.	DATE YY/MM/DD TIME HH:MM:SS	Date YY/MM/DD Time HH/MM/SS				3.18	25		
	ChA Total Unit#	Number of units in ChA system parallel connection	Set the number of UPS units connected in the UPS system.	1	*3 1 unit							
				2	2 units							
				3	3 units							
				4	4 units							
				5	5 units			*2			3.19	26
				6	6 units							
				7	7 units							
				8	8 units							
	ChB Total Unit#	Number of units in ChB system parallel connection	Do not change this setting .	1			*					
2												
3												
4												
5												
6												
7												
8												
Redundancy	UPS operation system	Redundant operation or single / parallel operation	N+1	Redundant operation					3.20	27		
			None	Single / parallel operation	*							
INPUT Phases	Input phase ★	Set number of input phases of UPS	Single 3Ph/4W *1	Single phase, 2 wires 3 phases, 4 wires	*				3.21	28		
SET DEFAULT (Initialization)	SET DEFAULT	Reset to factory defaults	—	—	—				3.22	29		


Note

- Do not set values marked with “*1”.
- The default value of “*2” is different depending on the UPS model. If you reset the value using “SET DEFAULT”, the value will not be set to its default but the one indicated by “*3”.
- For settings marked with “★”, after you change their values, the values will not take effect until you restart the UPS. Therefore, after changing the values, read §3.23 “Restarting UPS” and then start the UPS again. For details on UPS operation, refer to the *A11J Instruction Manual*. Before stopping the UPS, always be sure to stop the load device first.


§3.1 Setting Voltage

This section describes how to set the UPS voltage.

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows: “Home menu” → “Settings group” → “Settings” → “Values”
- ⑤ Use to switch values, and then press to select a desired value. When the confirmation screen appears, press again to accept the value.



Example: Change output voltage to “208V”



Tip

- *1. Pressing repeatedly cycles through the displayed items. If you miss a desired item, just keep on pressing until you see it again.
- *2. To return to the previous level, press .
- *3. When you switch to the values screen, the value shown is the current value, which is indicated by “>>”.
- *4. When a value has been changed and accepted, it is indicated by “@”. After you restart the UPS, the indication becomes “>>” (current value).

Details on settings and values

Values	Description
200V	Specify UPS output voltage.
220V	Input voltage and output voltage are the same.
230V	Check the input voltage and then select the same voltage.
240V	Check the input voltage and then select the same voltage.
208V	Check the input voltage and then select the same voltage.

If W1 type or W2 type is used, do not change the value. If you changed the value by mistake, use the procedure above to change it to 200V, and then restart the UPS.

- ⑥ Press to return to the home menu.


Note

- After you change a setting, read §3.23 “Restarting UPS” and then start the UPS again; otherwise, the change will not take effect. To stop the UPS, always stop the load device.
- If the UPS status display is “**Req. to restart**”: Values for settings are changed but you have not restarted the UPS. See §3.23 “Restarting UPS” and then restart the UPS.


§3.2 Setting Synchronous Frequency Tracking Range

This section describes how to specify a tracking range to synchronize the output frequency with the input frequency.

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Settings group” → “Settings” → “Values”
- ⑤ Use to switch values, and then press to select a desired value. When the confirmation screen appears, press again to accept the value.



Example: Change the synchronous frequency tracking range to “5%”



Tip

- *1. Pressing repeatedly cycles through the displayed items. If you miss a desired item, just keep on pressing until you see it again.
- *2. To return to the previous level, press .
- *3. When you switch to the values screen, the value shown is the current value, which is indicated by “>>”.
- *4. When a value has been changed and accepted, it is indicated by “@”. After you restart the UPS, the indication becomes “>>” (current value).

Details on settings and values

Values	Description
1 %	±1% of input frequency
3 %	±3% of input frequency
5 %	±5% of input frequency

- A smaller value provides better precision. However, if the input frequency is unstable, the UPS tends to switch to the asynchronous operation. To connect to output of the engine power generator, select 5%. During the asynchronous operation, if the UPS switches to the bypass operation, this will be instant cutoff switching.
- The inverter will not operate unless the input frequency is within the specified tracking range (±1%, ±3%, or ±5%) of the frequency setting in §3.3 (“50Hz”, “60Hz”, or “Auto”).

- ⑥ to return to the home menu.


Note

- After you change a setting, read §3.23 “Restarting UPS” and then start the UPS again; otherwise, the change will not take effect. To stop the UPS, always stop the load device.
- If the UPS status display is “Req. to restart”: Values for settings are changed but you have not restarted the UPS. See §3.23 “Restarting UPS” and then restart the UPS.


§3.3 Setting Frequency

The frequency has been set to “Auto” when the UPS is shipped from the factory. Do not change the value, except when using UPS in a special power supply environment. If you changed the value accidentally, use the procedure below to change it to “Auto”.

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Settings group” → “Settings” → “Values”
- ⑤ Use to switch values, and then press to select a desired value. When the confirmation screen appears, press again to accept the value.



Example: Set frequency to “Auto”



- Tip**
- *1. Pressing repeatedly cycles through the displayed items. If you miss a desired item, just keep on pressing until you see it again.
 - *2. To return to the previous level, press .
 - *3. When you switch to the values screen, the value shown is the current value, which is indicated by “>>”.
 - *4. When a value has been changed and accepted, it is indicated by “@>”. After you restart the UPS, the indication becomes “>>” (current value).

Details on settings and values

Value	Description	
Default → Auto	Set the output frequency to match the input frequency automatically.	If “Auto” is selected, when the frequency exceeds the tracking range set in §3.2 “Setting Synchronous Frequency Tracking Range”, the UPS switches to the asynchronous operation. If frequency exceeds $\pm 8\%$ of the specified frequency, the UPS switches to the battery operation.
50Hz	Set the output frequency to 50Hz.	If “50Hz” or “60Hz” is selected, the output frequency does not synchronize with the input frequency but the specified frequency is output. In this case, the input frequency's acceptable range is 40Hz to 120Hz. If this range is exceeded, the UPS switches to the battery operation. During UPS startup or recovery from battery operation, the operation same as that specified in the “Auto” setting is used.
60Hz	Set the output frequency to 60Hz.	

Contact SANYO DENKI beforehand if you need to change the frequency setting to “50Hz” or “60Hz”.

- The synchronous frequency tracking range ($\pm 1\%$, $\pm 3\%$, or $\pm 5\%$) is set in §3.2. Regardless of the frequency setting here (“50Hz”, “60Hz”, or “Auto”), the inverter will not start up unless the input frequency is within the specified tracking range.
- When “50Hz” or “60Hz” is set, the battery test described in §4.1 “Running Battery Test” is not available. Also, even if you set the battery test schedule to perform battery test automatically in §3.14 “Setting Battery Test Schedule”, the battery test will not be performed.
- When “50Hz” or “60Hz” is set, if the UPS switches to the bypass operation by manual switching operation or an overload, it will be instant cutoff switching.

- ⑥ Press to return to the home menu.

Note


- After you change a setting, read §3.23 “Restarting UPS” and then start the UPS again; otherwise, the change will not take effect. To stop the UPS, always stop the load device.
- If the UPS status display is “Req. to restart”: Values for settings are changed but you have not restarted the UPS. See §3.23 “Restarting UPS” and then restart the UPS.

§3.4 Setting Voltage for Measurement Display

This section describes how to specify an input/output voltage for measurement display.


If you have connected the UPS to a collector unit, change this setting according to the specifications of the collector unit.

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Settings group” → “Settings” → “Values”



- ⑤ Use to switch values, and then press to select a desired value. When the confirmation screen appears, press again to accept the value.

Example: Set display voltage to “200V/100V”



Tip

- *1. Pressing repeatedly cycles through the displayed items. If you miss a desired item, just keep on pressing until you see it again.
- *2. To return to the previous level, press .
- *3. When you switch to the values screen, the value shown is the current value, which is indicated by “>>”.
- *4. When a value has been changed and accepted, it is indicated by “>>” (current value).

Details on settings and values

Value	Description	
200V/200V (S)	If rated input voltage and output voltage are both 200V type	This is the default setting for S2 type or single-type. If the voltage is set to 200V, 220V, 230V, 240V, or 208V, this is the value used. If S2 type or single-operation type is used, do not change this setting.
200V/100V	If rated input voltage is 200V and output voltage is 100V	For W1 or W2 type, the default is different depending on the UPS model.
100V/200V	If rated input voltage is 100V and output voltage is 200V	If the PDU unit's terminal block is modified, change the value according to the specification.
100V/100V	If rated input voltage and output voltage are both 100V	For details on terminal block settings and values, refer to the <i>A11J Instruction Manual</i> .
200V/200V	If rated input voltage and output voltage are both 200V	

These are the values of voltage and current that appear on the LCD screen when UPS measurements are displayed. If you change the voltage, the current is also changed.

If the value is different from the UPS rated voltage, the measurements will not be displayed correctly.


If you have performed the operation described in §3.22 “Resetting Values of Settings”, the value becomes “200V/200V (S)”.

- ⑥ Press to return to the home menu.


§3.5 Setting PC Interface

This section describes how to specify an interface method when a PC interface connector is used. For details on PC interface connector, refer to §5.4 “External Interface” in the *A11J Instruction Manual*.

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Settings group” → “Settings” → “Values”
- ⑤ Use to switch values, and then press to select a desired value. When the confirmation screen appears, press again to accept the value.



Example: Set interface to “Standalone”



Details on settings and values

Value	Description
Standalone (Standalone)	Select this value for the following cases. * Standard UPS service of OS * UPS remote ON/OFF using remote switch
WS (Workstation)	Select this value for the following cases. * Power management software * LAN interface card * Computer one-touch shutdown using remote switch
Terminal (Terminal)	Do not use this value.

Default

Tip

*1. Pressing repeatedly cycles through the displayed items. If you miss a desired item, just keep on pressing until you see it again.

*2. To return to the previous level, press .

*3. When you switch to the values screen, the value shown is the current value, which is indicated by “>>”.


*4. When a value has been changed and accepted, it is indicated by “>>>” (current value).

- ⑥ Press to return to the home menu.


§3.6 Setting Baud Rate

This section describes how to specify a baud rate for connection to a workstation, PC, or LAN interface card.

- ① Press **HOME** to display the LCD screen.
- ② Press **ITEM** to change the home menu to the one shown below.
- ③ Press **SELECT** to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Settings group” → “Settings” → “Values”
- ⑤ Use **ITEM** to switch values, and then press **SELECT** to select a desired value. When the confirmation screen appears, press **SELECT** again to accept the value.



Example: Set baud rate to “4800”



Tip

- *1. Pressing **ITEM** repeatedly cycles through the displayed items. If you miss a desired item, just keep on pressing until you see it again.
- *2. To return to the previous level, press **BACK**.
- *3. When you switch to the values screen, the value shown is the current value, which is indicated by “>>”.
- *4. When a value has been changed and accepted, it is indicated by “>>” (current value).

Details on settings and values

	Value	Description
Default	9600	Baud rate 9600 bps
	4800	Baud rate 4800 bps
	2400	Baud rate 2400 bps


When a LAN interface card is used, set the baud rate to 9600 bps.

- ⑥ Press **HOME** to return to the home menu.


§3.7 Setting UPS Operation Upon Power Recovery

This section describes how to specify an operation to use in utility power recovery after the UPS is stopped by end of battery discharge during power outage.

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Settings group” → “Settings” → “Values”
- ⑤ Use to switch values, and then press to select a desired value. When the confirmation screen appears, press again to accept the value.



Example: Specify “STOP” as the operation for power recovery.



Details on settings and values

	Value	Description
Default	Auto	Automatic The UPS restarts automatically when the utility power recovers.
	Any Condition	Always start The UPS always starts automatically when input power is received, regardless of whether it is power recovery after outage or input power is received at initial startup.
	STOP	Stop The UPS stays off even when the utility power recovers. However, if “BYPASS” is selected in §3.11, bypass power is used.
	BATT > 30%	More than 30% The UPS restarts automatically when battery charge reaches 30% if the utility power recovers.
	BATT > 50%	More than 50% The UPS restarts automatically when battery charge reaches 50% if the utility power recovers.
	BATT > 80%	More than 80% The UPS restarts automatically when battery charge reaches 80% if the utility power recovers.

When power management software is used, the UPS starts at the charging rate specified by the power management software. Even if you set this item by the procedures above, the value cannot be enabled. In such a case, when you display the value by the procedures above, the value of power management software appears as follows.

Example:

Start Condition BATT > 5%(Val)

 “(Val)” at the end of the value indicates the value set by power management software.


When you press , this value disappears. Press to go back once, and then press , it is displayed again.

- ⑥ Press to return to the home menu.


§3.8 Setting Buzzer Condition

This section describes how to specify a condition to sound the buzzer.

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Settings group” → “Settings” → “Values”
- ⑤ Use to switch values, and then press to select a desired value. When the confirmation screen appears, press again to accept the value.



Example: Specify “Group #2” as a condition to sound the buzzer



Tip



- *1. Pressing repeatedly cycles through the displayed items. If you miss a desired item, just keep on pressing until you see it again.
- *2. To return to the previous level, press .
- *3. When you switch to the values screen, the value shown is the current value, which is indicated by “>>”.
- *4. When a value has been changed and accepted, it is indicated by “>>” (current value).







Details on settings and values


Value	Description
Default → ALL All states	Buzzer beeps in following cases: Battery operation, battery testing, battery voltage error, low battery voltage, overload (bypass operation), battery life end warning, battery life end, serious malfunction, minor malfunction, end of discharge, request for buzzer from power management software. (Button operation sounds are also enabled.)
Group #1 Group 1	Buzzer beeps in following cases: Low battery voltage, battery life end warning, battery life end, serious malfunction, minor malfunction, end of discharge, request for buzzer from power management software. (Button operation sounds are also enabled.)
Group #2 Group 2	Buzzer beeps in following cases: Serious malfunction, request for buzzer from power management software. (Button operation sounds are also enabled.)
SILENT Stop	Only the button operation sounds are enabled.

- ⑥ Press to return to the home menu.


§3.9 Setting UPS Shutdown Operation

This section describes how to shut down the UPS using  on its control panel. This setting prevents unintended contact or accidental operation of the button to cause the UPS to stop. On the control panel, only the “OFF operation” of  is enabled, but the “ON operation” cannot be changed.





- ① Press  to display the LCD screen.
- ② Press  to change the home menu to the one shown below.
- ③ Press  to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Settings group” → “Settings” → “Values”
- ⑤ Use  to switch values, and then press  to select a desired value. When the confirmation screen appears, press  again to accept the value.




Example: Shut down UPS in “3 Sec” (3 seconds)



Details on settings and values


	Value	Description
Default	1 Sec. 1 second	Pressing  for 1 second shuts down the UPS.
	3 Sec. 3 seconds	Pressing  for 3 seconds shuts down the UPS.
	Unique Special operation	Press and hold  for 3 seconds and then release the button when the buzzer starts beeping. While the buzzer is still beeping, press  for 3 seconds to shut down the UPS.

- ⑥ Press  to return to the home menu.


§3.10 Setting Overload Recovery Operation

This section describes how to specify a condition for returning to UPS power supply after switching to bypass power because of overload.

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Settings group” → “Settings” → “Values”
- ⑤ Use to switch values, and then press to select a desired value. When the confirmation screen appears, press again to accept the value.



Example: Set overload operation to “Auto Ret BYP” (Automatic return)




Details on settings and values







Value	Description
Auto Ret BYP	Automatic return After overload causes power to switch to bypass power supply, power switches back to UPS power supply automatically after a certain period of time. If overload continues, power switches to bypass power supply again, and this operation repeats.
Default Stay on BYP	Bypass power supply If overload continues, bypass power supply continues. If overload goes away, power switches back to UPS power supply. When power switches to bypass power supply, the power continues to switch between UPS power supply and bypass power supply depending on the utility power voltage value.
Output OFF	Stop output Do not use this value.


- Regardless of the setting above (“Auto Ret BYP” or “Stay on BYP”), the UPS cannot switch to UPS power supply from bypass power supply during asynchronous operation (when the input frequency is not within the specified tracking range ($\pm 1\%$, $\pm 3\%$, or $\pm 5\%$) set in §3.2).
- Under the condition below, the UPS switches to the bypass operation with instant interruption.
 - When “50Hz” or “60Hz” is set in §3.3 “Setting frequency.”
 - When “Auto” is set in §3.3 “Setting frequency” and during asynchronous operation.

- ⑥ Press to return to the home menu.


§3.11 Setting UPS Operation at OFF


This section describes how to specify UPS power supply when the  button's OFF operation performed in “UPS Shutdown” of the *A11J Instruction Manual* causes the UPS to stop (**MAIN MCCB** is ON).

- ① Press  to display the LCD screen.
- ② Press  to change the home menu to the one shown below.
- ③ Press  to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Settings group” → “Settings” → “Values”
- ⑤ Use  to switch values, and then press  to select a desired value. When the confirmation screen appears, press  again to accept the value.



Example: Set power supply when button is OFF to “BYPASS” (bypass power supply)



- ⑥ Press  to return to the home menu.


Note

- After you change a setting, read §3.23 “Restarting UPS” and then start the UPS again; otherwise, the change will not take effect. However, if the current setting is “BYPASS”, setting the UPS's **MAIN MCCB** to OFF does not stop the UPS. Therefore, cut off the breaker distribution board on the input side of the UPS, stop the UPS, and then start it again. To stop the UPS, always stop the load devices first.
- If the UPS status display is “Req. to restart”:
Values for settings are changed but they require restart of the UPS before their changes take effect. Therefore, see §3.23 “Restarting UPS” and then restart the UPS.


§3.12 Setting Low Battery Voltage Warning Timing

This section describes how to set the time to issue low battery voltage warning.

- Press **HOME** to display the LCD screen.
- Press **ITEM** to change the home menu to the one shown below.
- Press **SELECT** to accept it.
- In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Settings group” → “Settings” → “Values”
- Use **ITEM** to switch values, and then press **SELECT** to select a desired value. When the confirmation screen appears, press **SELECT** again to accept the value.



Example: Set time to issue warning to “3 Min.” (3 minutes)



Details on settings and values

Value		Description
Default	Voltage	When low battery voltage is detected, issue warning. “Batt Vol low” appears on the LCD screen and the buzzer beeps.
2 Min.	2 minutes	When the battery's remaining capacity is less than 2 minutes*, issue warning.
3 Min.	3 minutes	When the battery's remaining capacity is less than 3 minutes*, issue warning.
5 Min.	5 minutes	When the battery's remaining capacity is less than 5 minutes*, issue warning.
10 Min.	10 minutes	When the battery's remaining capacity is less than 10 minutes*, issue warning.
		When using 5 min. or 10 min. backup type UPS, or when the load factor is 30% or less, do not use these values.

* The time (minutes) is only an approximation. Refer to §8 “Notes on UPS Measurements Information.”

- If the setting in §3.8 “Setting Buzzer Condition” is “SILENT” or “Group #2”, the buzzer does not beep.
- When power management software is used, warning is issued at the time set by the power management software to shut down the UPS. Even if you set this item by the procedures above, the value cannot be enabled. In such a case, when you display the value by the procedures above, the value of power management software appears as follows.

Example:

BATLV Timing 4 Min. (Val)

 “(Val)” at the end of the value indicates the value set by power management software.


When you press **ITEM**, this value disappears. Press **BACK** to go back once, and then press **SELECT**, it is displayed again.

- Press **HOME** to return to the home menu.


§3.13 Setting Battery Test Time

This section describes how to set a duration to run a battery test either regularly or manually.

- ① Press **HOME** to display the LCD screen.
- ② Press **ITEM** to change the home menu to the one shown below.
- ③ Press **SELECT** to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Settings group” → “Settings” → “Values”
- ⑤ Use **ITEM** to switch values, and then press **SELECT** to select a desired value. When the confirmation screen appears, press **SELECT** again to accept the value.



Example: Set battery test time to “5 Min.” (5 minutes)



Details on settings and values

	Value	Description
Default	2 Min. 2 minutes	Run battery test for 2 minutes.
	5 Min. 5 minutes	Run battery test for 5 minutes.
	10 Min. 10 minutes	Run battery test for 10 minutes.
	20 Min. 20 minutes	Run battery test for 20 minutes.


Set battery test time according to the battery capacity and load capacity connected to the UPS.

- ⑥ Press **HOME** to return to the home menu.


§3.14 Setting Battery Test Schedule

This section describes how to set a schedule (number of days) to run an automatic battery test. The test is carried out automatically when the specified number of days has elapsed.

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Settings group” → “Settings” → “Values”
- ⑤ Use to switch values, and then press to select a desired value. When the confirmation screen appears, press again to accept the value.



Example: Set battery test interval to “90 Days”



Tip

- *1. Pressing repeatedly cycles through the displayed items. If you miss a desired item, just keep on pressing until you see it again.
- *2. To return to the previous level, press .
- *3. When you switch to the values screen, the value shown is the current value, which is indicated by “>>”.
- *4. When a value has been changed and accepted, it is indicated by “>>” (current value).

Details on settings and values

	Value	Description
Default	180 Days	180 days
	90 Days	90 days
	30 Days	30 days
	None	No

- This function is available only when “Auto” is set in §3.3 “Setting Frequency”. If “50Hz” or “60Hz” is set, the battery test will not be performed.
- When power management software is used, battery test is performed according to the schedule set by the power management software. If you set to the different value from power management software by the procedures above, the value is once changed. However, when you display the value again, the value set by the power management software is displayed.

- ⑥ Press to return to the home menu.


§3.15 Setting Backup Time During Power Outage

This section describes how to specify the time from when the UPS starts backup to when output supply stops.


Note

This function is enabled only when “Standalone” is set in §3.5 “Setting PC Interface”. See page 12 to check the interface setting. When “WS” is set, change the setting to “Standalone”. The default setting is “WS” (workstation).

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Settings group” → “Settings” → “Values”
- ⑤ Use to switch values, and then press to select a desired value. When the confirmation screen appears, press again to accept the value.



Example: Set backup time at power outage to “3 Min.” (3 minutes)



Tip

- *1. Pressing repeatedly cycles through the displayed items. If you miss a desired item, just keep on pressing until you see it again.
- *2. To return to the previous level, press .
- *3. When you switch to the values screen, the value shown is the current value, which is indicated by “>>”.
- *4. When a value has been changed and accepted, it is indicated by “>>” (current value).

Details on settings and values

	Value	Description
Default	BATT EV	End of battery discharge Continue output supply until the end of battery discharge. Select this one to maximize use of the battery capacity.
	10 Sec.	10 seconds Provide backup for 10 seconds, and then stop output supply.
	30 Sec.	30 seconds Provide backup for 30 seconds, and then stop output supply.
	1 Min.	1 minute Provide backup for 1 minute, and then stop output supply.
	3 Min.	3 minutes Provide backup for 3 minutes, and then stop output supply.
	5 Min.	5 minutes Provide backup for 5 minutes, and then stop output supply.
	10 Min.	10 minutes Provide backup for 10 minutes, and then stop output supply.

- When the specified time has elapsed, the output supply stops. If utility power supply recovers within the specified time, the UPS returns to normal operation. When using this function, set the interface setting to “Standalone” in §3.5 “Setting PC Interface. If “WS” is set, this function is not enabled. The default setting is “WS” (workstation).
- However, even if you select “** Sec.” or “** Min.”, the specified time may not be provided depending on the conditions such as the battery configuration, the load factor, the insufficient battery charging, the remaining battery service life, or an ambient temperature.

- ⑥ Press to return to the home menu.


§3.16 Setting RING Signal *

This section describes specifying whether to output the RING signal when the UPS starts.


* What is a RING signal?

This is a signal which starts a connected computer automatically when the UPS starts. This function is enabled if a computer supporting the “Wake Up on Ring” function is connected to the UPS with the communication cable (optional).

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows: “Home menu” → “Settings group” → “Settings” → “Values”
- ⑤ Use to switch values, and then press to select a desired value. When the confirmation screen appears, press again to accept the value.



Example: Set Ring signal to “Output” (Output)




- ⑥ Press to return to the home menu.


§3.17 Setting Adjustment for Output Voltage

This section describes how to set adjustment for the output voltage set up in §3.1 “Setting Voltage”. Three levels on the plus side and three levels on the minus side (about -3V to +3V) can be selected.

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Settings group” → “Settings” → “Values”
- ⑤ Use to switch values, and then press to select a desired value. When the confirmation screen appears, press again to accept the value.



Example: Set adjustment to “+1”



Details on settings and values

Value	Description
-3	Set 3 levels on the minus side (about 3V).
-2	Set 2 levels on the minus side (about 2V).
-1	Set 1 level lower on the minus side (about 1V).
Default	0
	Output specified voltage as it is.
+1	Set 1 level on the plus side (about 1V).
+2	Set 2 levels on the plus side (about 2V).
+3	Set 3 levels on the plus side (about 3V).


Adjustment can be made by specifying the number of levels, with each level being about 1V. The adjustment values indicated above are those when the setting in §3.4 “Setting Voltage for Measurement Display” is “200V/200V” or “100V/200V” (output voltage 200V type). If the setting is “200V/100V” or “100V/100V” (output voltage 100V type), the value becomes half. The selected value is used for adjustment of the output voltage set in §3.1 “Setting Voltage”. According to the state of the connected load devices and installation environment, set up the adjustment.

- ⑥ Press to return to the home menu.



§3.18 Setting Clock

This section describes how to set the UPS clock. Because the clock has been set when the UPS is shipped from the factory, normally do not change the clock.


- ① Press **HOME** to display the LCD screen.
- ② Press **ITEM** to change the home menu to the one shown below.
- ③ Press **SELECT** to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Setting group” → “Setting” → “Value”
- ⑤ Use **ITEM** to switch values, and then press **SELECT** to select a desired value. Repeat this operation. When the confirmation screen appears, press **SELECT** again to accept the value.



Example: Set the clock to “9:50 AM, January 20, 2010”



When you switch to a setting, the value that appears is the current value set for the setting. If you want to change the value, select a different one. When you change the time, the “seconds” field becomes 0.




- ⑥ Press **HOME** to return to the home menu.


§3.19 Setting Number of UPS Units in Parallel Connection

This section describes how to specify the number of UPS units in parallel connection to form a UPS system. Because this value has been set at the factory, normally do not change it.

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Setting group” → “Setting” → “Value”
- ⑤ Use to switch values, and then press to select a desired value. When the confirmation screen appears, press again to accept the value.



Example: Set the number of UPS units to “3”



Details on settings and values

Value	Description
1	One UPS unit is used.
2	2 UPS units are connected.
3	3 UPS units are connected.
4	4 UPS units are connected.
5	5 UPS units are connected.
6	6 UPS units are connected.
7	7 UPS units are connected.
8	8 UPS units are connected.

The default is different depending on the UPS model.

Note

ChB Total Unit# has a value of 1. Do not change it. If you have changed the value by mistake, select **ChB Total Unit#** and then use the same procedure to change its value.

If you have added a UPS unit or changed the number of UPS units connected, change this setting to match the number of UPS units actually connected. If a UPS unit stops during operation for some reason so that the number of operating UPS units does not match the setting, the message “Total Unit# Err” appears in the UPS status display on the LCD panel.


After you perform the operation in §3.22 “Resetting Values of Settings”, this setting returns to 1. In this case, check the number of UPS units in the system and then change the setting again.

- ⑥ Press to return to the home menu.


§3.20 Setting Operation System

This section describes how to specify the UPS operation system. You can choose between parallel redundant operation or single machine/parallel operation.

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Setting group” → “Setting” → “Value”
- ⑤ Use to switch values, and then press to select a desired value. When the confirmation screen appears, press again to accept the value.



Example: Set operation system to “N+1”



Details on settings and values

Value	Description	
N+1	Parallel redundant operation	* Parallel redundant operation system: where there is surplus of one unit from UPS units in parallel connection to handle load capacity
Default → None	Single / parallel operation	* Single operation system: where there is one UPS unit * Parallel operation system: where total capacity of UPS units in parallel connection is used as connectable load capacity in operation

If “N+1” is selected, when there is no surplus of one UPS unit for load capacity connected to UPS, the LCD screen displays “FT Disabled”. In this case, reduce the load connected to UPS.


However, the load factor value “LF = %” displayed by viewing UPS measurements is same even when either setting value (“N+1” or “None”) is set. See §8 “Notes on UPS Measurements Information” for details.

- ⑥ Press to return to the home menu.

§3.21 Setting Input Phase

This section describes how to specify the UPS input phase.


- ① Press **HOME** to display the LCD screen.
- ② Press **ITEM** to change the home menu to the one shown below.
- ③ Press **SELECT** to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Setting group” → “Setting” → “Value”
- ⑤ Use **ITEM** to switch values, and then press **SELECT** to select a desired value. When the confirmation screen appears, press **SELECT** again to accept the value.



Example: Set input phase to “3Ph/4W” (3 phases, 4 wires)

While this example uses “3Ph/4W” in explaining the procedure, keep the setting at “Single” in this UPS system and do not change it.

- Tip**
- *1. Pressing **ITEM** repeatedly cycles through the displayed items. If you miss a desired item, just keep on pressing until you see it again.
 - *2. To return to the previous level, press **BACK**.
 - *3. When you switch to the values screen, the value shown is the current value, which is indicated by “>>”.
 - *4. When a value has been changed and accepted, it is indicated by “@>”. After you restart the UPS, the indication becomes “>>” (current value).



- ⑥ Press **HOME** to return to the home menu.


Note

- After you change a setting, read §3.23 “Restarting UPS” and then start the UPS again; otherwise, the change will not take effect. To stop the UPS, always stop the load device.
- If the UPS status display is “**Req. to restart**”:
Values for settings are changed but you have not restarted the UPS. See §3.23 “Restarting UPS” and then restart the UPS.


§3.22 Resetting Values of Settings

This section describes how to restore settings mentioned in sections §3.1 to §3.21 back to their factory defaults. Use the list in §3. “Setting UPS” to check the factory defaults. Once you restore the settings back to their factory defaults, you cannot return to their previous values.

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Settings group”
- ⑤ Press to display the confirmation screen, and then press again to reset the value.



Example: Resetting the settings



Tip

- *1. Pressing repeatedly cycles through the displayed items. If you miss a desired item, just keep on pressing until you see it again.
- *2. To return to the previous level, press .

- ⑥ Press to return to the home menu.

Note

- For the following settings, resetting them does not restore their values to the factory defaults but the values listed below. Therefore, Make the necessary changes according to the UPS system specifications.

Section	Setting (section title)	Value after reset
§3.4	Setting Voltage for Measurement Display	200V/200V (S)
§3.19	Setting Number of UPS Units in Parallel Connection	1

- For settings that require restarting the UPS to make the changes effective, you must restart the UPS after resetting the settings. In this case, “Req. to restart” appears in the UPS status display. See 3.23 “Restarting UPS” and then restart the UPS. When you stop the UPS, always stop the load devices first.


§3.23 Restarting* UPS

* What is restarting?

It means stopping the operating UPS and then starting it again.
If “Please restart the UPS” is mentioned in the LCD Panel Operating Manual (this manual) or A11J Instruction Manual with reference to enabling changes in settings to take effect, stop the operating UPS, wait for the specified time to elapse, and then restart the UPS.

For settings listed on page 6 with the “★” mark, after you change the settings, the changes do not take effect until you restart the UPS. Therefore, after you change settings with the “★” mark, use the following procedure to restart the UPS.

Depending on the UPS model, the procedure to stop and then start it is different. For details, refer to “UPS Operation” in the *A11J Instruction Manual*. Before you stop the UPS, be sure to stop the load devices first.



§4. Operating UPS

You can perform three operations from the CONTROL menu: running battery test, starting/stopping UPS, and switching to bypass operation. For details on the operations, see the sections from §4.1 to §4.4.

List of operations

Home menu: CONTROL

Operation		Displayed item		Displayed content				Ref item	Ref page		
Display	Description	Display	Description	Display	Description	Result	Description				
BATTERY TEST	Run battery test	Start	Start	[SELECT] = OK	OK to start	Control NG	Operation canceled	4.1	32		
				[BACK] = Cancel	Cancel	Control OK	Normal termination				
		STATUS	Test status	Test Condition	Test result		Possible		Test can start	4.2	34
							Impossible		Test cannot start		
							Testing		Test in progress		
				Last Test Time	Date of last test	YY/MM/DD HH:MM	YY/MM/DD HH:MM				
				Last Result	Result of last test		BATTST:OK		Normal		
	BATTST:NG		Error								
	BATTST:No Result		No previous result								
	BATTST>Error		Error								
			BATTST:Suspended		Aborted						
INV ON	Start UPS	[SELECT] = OK	ON	Control NG	Operation canceled	Control OK	Normal termination	4.3	35		
		[BACK] = Cancel	Cancel								
INV OFF	Stop UPS	[SELECT] = OK	OFF	Control NG	Operation canceled	Control OK	Normal termination	4.3	35		
		[BACK] = Cancel	Cancel								
BYPASS	Change bypass operation	[SELECT] = OK	Switch	Control NG	Operation canceled	Control OK	Normal termination	4.4	36		
		[BACK] = Cancel	Cancel								



§4.1 Running Battery Test

This section describes how to run a battery test. By default, a battery test is carried out automatically once every 180 days. If you want to run a battery test manually, use the following procedure. You can do this without stopping the load devices connected to the UPS. However, if the UPS has performed a backup operation within 12 hours prior to the test, the result may show an error. Perform the battery test when the UPS has not performed a backup operation within the last 12 hours.

Tip

- You can change the battery test time (min.). See §3.13 "Setting Battery Test Time".
- You can change the battery test schedule (interval) of automatic battery test. See §3.14 "Setting Battery Test Schedule".


- Press **HOME** to display the LCD screen.
- Press **ITEM** to change the home menu to the one shown below.
- Press **SELECT** to accept it.
- In the same way, follow the figure below to make selection at each level, as follows: "Home menu" → "Operation" and continue
- Use **ITEM** to switch items, and then press **SELECT** to select a desired item. When the confirmation screen appears, press **SELECT** to perform the operation.



Battery test's displayed content

Item		Content	
Display	Description	Display	Description
Test Condition	Test condition	Possible	Test can start
		Impossible	Test cannot start
		Testing	Test in progress
Last Test Time	Date and time of last battery test	YY/MM/DD HH:MM	YY/MM/DD HH:MM If "**/**/** **:**" appears, this indicates the last test result does not exist.
Last Result	Last battery test result	BATTST:OK	Battery is normal.
		BATTST:NG	Battery malfunction may exist.
		BATTST:No Result	Last battery test result does not exist.
		BATTST:Error	Error occurs. Battery test fails due to some kind of error.
		BATTST:Suspended	Test is canceled.

- Press **HOME** to return to the home menu.

- *3. If “Control NG” appears and the battery test could not be performed, the UPS may be in a state which renders battery test not possible. In this case, use  to go back, check the UPS state, and then try again.

Note on battery test


The result serves as a general guide only. Even if the result is normal, refer to “General Guide on Battery Replacement” in *the A11J Instruction Manual* and, if the replacement time has come, contact your supplier or SANYO DENKI as soon as possible.

Cases where battery test is not possible

- In cases ① to ⑦, battery test is not possible.


① While inverter stops	④ During shutdown by remote operation, etc.
② During bypass power supply	⑤ UPS malfunction
③ During battery operation	⑥ During asynchronous operation
	⑦ When “50Hz” or “60Hz” is set in §3.3 “Setting Frequency”

Canceling battery test

- To cancel during battery test...
When “Cancel” appears on the LCD screen, press  ⇒ UPS returns to normal operation.
- During battery test, if any of ① to ③ occurs, or if any of ④ to ⑦ is performed, the battery test is canceled.

① Input error (voltage, frequency)	④ Forced to bypass switch
② UPS malfunction	⑤ MAIN MCCB is set to “OFF”
③ Output overcurrent	⑥ UPS's OFF operation is performed
	⑦ Battery test is canceled by power management software



- *4. To cancel battery test...
Follow the steps below.



§4.2 Reading Battery Test Result

This section describes how to read the battery test result generated during a battery test performed either automatically or manually.

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Operation” and continue
- ⑤ Use to switch items, and then press to select and display it.



Tip

- *1. Pressing repeatedly cycles through the displayed items. If you miss a desired item, just keep on pressing until you see it again.
- *2. To return to the previous level, press .

Battery test's displayed content


Item		Content	
Display	Description	Display	Description
Test Condition	Test condition	Possible	Test can start
		Impossible	Test cannot start
		Testing	Test in progress
Last Test Time	Date and time of last battery test	YY/MM/DD HH:MM	YY/MM/DD HH:MM If “**/**/** **:*” appears, this indicates the last test result does not exist.
Last Result	Last battery test result	BATTST:OK	Battery is normal.
		BATTST:NG	Battery malfunction may exist.
		BATTST:No Result	Last battery test result does not exist.
		BATTST:Error	Error occurs. Battery test fails due to some kind of error.
		BATTST:Suspended	Test is canceled.

- ⑥ Press to return to the home menu.


§4.3 Starting or Stopping UPS

From the LCD panel, you can use the CONTROL menu to start or stop the UPS system. When you perform this operation, the entire UPS system starts or stops. It is not possible to use this operation to start or stop individual UPS units. Before stopping the UPS system, be sure to stop the load devices first.

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Operation” and continue
- ⑤ Use to switch items, and then press to select a desired item. When the confirmation screen appears, press to perform the operation.



Example: Stopping UPS



Note on starting or stopping UPS

The operations are not possible in the following cases.

➤ UPS cannot start when:

- ① Inverter is starting up.
- ② Input voltage and input frequency exceed rated range
- ③ UPS is malfunctioning

➤ UPS cannot stop when:

- ① During bypass operation
- ② Inverter stops

- ④ During continuous input of Remote OFF signal
- ⑤ During EPO signal input
- ⑥ Forced bypass switch **Forced Bypass** is on “Bypass” side.

Starting or stopping UPS with ON/OFF button



You can also use the button on the LCD panel or the button on the main unit's control panel to start or stop the UPS. For details, refer to “Performing Operation” in the *A11J Instruction Manual*.

- ⑥ Press to return to the home menu.

§4.4 Switching to Bypass Operation

You can switch the UPS operation to the bypass operation using following procedures if a UPS malfunction occurs or when maintaining the UPS.

- ① Press to display the LCD screen.
- ② Press to change the home menu to the one shown below.
- ③ Press to accept it.
- ④ In the same way, follow the figure below to make selection at each level, as follows:
“Home menu” → “Operation” and continue
- ⑤ Use to switch items, and then press to select a desired item. When the confirmation screen appears, press to perform the operation.



Note on switching to bypass operation

- When the UPS is malfunctioning and the output power supply stopped, you cannot switch to the bypass operation by the procedure above.
- When “Auto” is set in §3.3 “Setting frequency”, the UPS switches to bypass operation without interruption during synchronous operation. During asynchronous operation, the UPS switches with instant interruption. When “50Hz” or “60Hz”, the UPS switches to bypass operation with instant interruption.
- You can also switch the UPS operation to the bypass operation using **Forced Bypass** inside the front panel of the UPS.
- Note that during the bypass operation, if you set **MAIN MCCB** to “OFF”, “By Fuse Error” appears on the LCD screen, “Red WARNING” and “Red ALARM” light, and output supply stops. Setting **MAIN MCCB** to “ON” returns to bypass operation.

How to switch from bypass operation to inverter operation

Use either method A or B below to switch to the inverter operation.

- A. Use the button on the LCD panel or the button on the main unit's control panel to perform the ON operation.
- B. In the operation step of §4.3 “Starting or Stopping UPS”, select “CONTROL INV ON”.
See §4.3 “Starting or Stopping UPS” for details on the procedure.

When “Auto” is set in §3.3 “Setting frequency”, even if you perform A or B procedure above, the UPS can not switch to inverter operation during asynchronous operation. When “50Hz” or “60Hz” is set, the UPS can not switch to inverter operation unless the input frequency is within the specified tracking range ($\pm 1\%$, $\pm 3\%$, or $\pm 5\%$) set in §3.2 “Setting Synchronous Frequency Tracking Range.”

- ⑥ Press to return to the home menu.

§5. Maintenance Menu (For Service Technician*)

The maintenance menu is intended for use by a service technician to perform maintenance of the UPS. Even though details are described in §6. "Menu List", do not use the menu to perform any operation.

The operation is described in the maintenance manual for service technician.

* Service technician

This term is used to indicate service technicians from SANYO DENKI or entrusted by SANYO DENKI with knowledge of this UPS. Maintenance work must not be performed by other than a qualified service technician.

§6. Menu List

1. STATUS

Home menu	UPS mode		Status display			
	Display	Description	Display	Description	Display	Description
STATUS (UPS status display)	STANDBY	Standby	Output Not Sync	Asynchronous operation	Batt Life End	End of battery life
	ONLINE	Online	Input Freq Err	Input frequency error	Batt Life Warn	Battery life end warning
	BYPASS	During bypass operation	Input Vol Hi	High input voltage	Batt Vol Error	Battery voltage error
			Input Vol Low	Low input voltage	Batt Vol End	End of battery discharge
	BATTERY	During battery operation	Input Error	Input error	Batt Vol Low	Low battery voltage
	BATT TEST	During battery testing	INV Vol Hi	High inverter voltage (serious malfunction)	CHG Error	Charger error (serious malfunction)
			INV Vol Low	Low inverter voltage (serious malfunction)	CONV Error	Converter error (serious malfunction)
	SYS FAILURE	During system malfunction	INV Vol Error	Inverter voltage detection circuit error (serious malfunction)	BF Circuit Error	Back feed prevention circuit error (serious malfunction)
			Output Stop (HV)	Bypass output stopped (excessive voltage)	FIN Temp Error	Fin temperature error (serious malfunction)
			Over Load	Overload	DSP Error	Controller error (serious malfunction)
			Vo= V Fo= Hz	Output voltage, output frequency	BUS Error	DC voltage error (serious malfunction)
			Vi= V Fi= Hz	Input voltage, input frequency	AUX2 Error	Auxiliary power error (minor malfunction)
			LF= % CHG= % *	Load factor %, Charging rate %	Total Unit# Err	Total number of units error (serious malfunction)
			LF= % Tim= m *	Load factor %, Charging duration minutes	LCD Error	LCD panel error
			Byp Fuse Error	Bypass fuse error	Minor Error	Minor malfunction
			Bypass SW ON	Bypass switch ON	Fatal Error	Serious malfunction
			Req To Restart	Restart is necessary.	FT Disabled	Redundant operation not allowed
			Remote	Battery test by remote operation in progress	Check Unit Error	Device error exists and checking is required.
			Remote OFF	Operation stops due to remote OFF.	EPO ON	Operation stopping due to EPO
	Output Not Sync	Asynchronous operation	Batt Life End	End of battery life		
Input Freq Err	Input frequency error	Batt Life Warn	Battery life end warning			

* Refer to §8 "Notes on UPS Measurements Information."

2. MEASUREMENT

Home menu	Measurement setting		Measurements displayed	
	Display	Description	Display	Description
MEASUREMENT (measurements displayed)	INPUT	Input measurements	Vin = V	Input voltage
			Fin = Hz	Input frequency
	OUTPUT	Output measurements	Vout = V	Output voltage
			Iout = A	Output current
			LF = % *	Load factor
			Watt = kW	Output power
			Fout = Hz	Output frequency
	BATTERY	Battery measurements	Vbatt = V	Battery voltage
			ChgRate = % *	Battery charging rate
			RunTm = Min. *	Battery retention time
			Power Failure Times	Number of outages
			Battery Life Years	Battery life
	CHARGER	Charger measurements	Backup OPE. Time Sec.	Accumulated time on battery operation
			Vchg = V	Charger voltage
	TEMPERATURE	Temperature measurements	Ichg = A	Charger current
			T-Amb = ° C	Ambient temperature

* Refer to §8 "Notes on UPS Measurements Information."

3. SETTING

Home menu	Settings group	Settings			Values		Default setting
		Display	Content	Description	Display	Description	
SETTING (various settings)	SET IN/OUT (input/output setting)	Voltage	Output voltage ★	Set UPS output voltage. Same as input voltage	200V 220V 230V 240V 208V	Output voltage 200V Output voltage 220V Output voltage 230V Output voltage 240V Output voltage 208V	*
		FREQ Range	Synchronous frequency tracking range ★	Set range (%) at which the output frequency tracks input frequency	1% 3% 5%	±1% ±3% ±5%	*
		Frequency	Output frequency ★	Set output frequency.	Auto 50Hz 60Hz	Automatic selection Fixed at 50Hz Fixed at 60Hz	*
		Display	Voltage current display	Set input/output voltage and current for measurements display etc.	200V/200V(S) 200V/100V 100V/200V 100V/100V 200V/200V	200V/200V(S) 200V/100V 100V/200V 100V/100V 200V/200V	Differs depending on UPS model
	SET I/F (interface setting)	Interface	Interface	Set interface for using PC interface connector.	Standalone WS Terminal *1	Standalone Workstation Terminal	*
		Baud Rate	Baud rate	Set baud rate for connection with PC, LAN card, or Workstation.	9600 4800 2400	9600bps 4800bps 2400bps	*
	SET OPERATION (operation setting)	Start Condition	Specify operation during power recovery.	Set UPS operation to perform when utility power recovers, after UPS stops due to end of battery discharge in power outage.	Auto Any Condition STOP BATT>30% BATT>50% BATT>80%	Automatic Always start Stop Start when charging rate reaches 30% Start when charging rate reaches 50% Start when charging rate reaches 80%.	*
		BUZZER	Buzzer sound	Set when the buzzer should beep.	ALL Group #1 Group #2 SILENT	All Group 1 Group 2 Stop	*
		OFF Operation	Operation of OFF	Set how to turn off (⊙) on the operation panel of the main unit to stop the UPS.	1 Sec. 3 Sec. Unique	Turn off when pressed for 1 second. Turn off when pressed for 3 seconds. Turn off by special operation.	*
		OVER Load	Overload operation	Set what to do after power supply switches to bypass due to overload.	Auto Ret BYP Stay on BYP Output OFF *1	Automatic recovery from bypass Bypass power supply during overload Stop output	*
Output @OFF		Power supply during OFF ★	Set output's power supply state when UPS stops.	OFF BYPASS	Stop output Bypass power supply	*	
SET BATTERY (battery setting)		BATLV Timing	BATLV timing	Set when to issue battery voltage low warning.	Voltage 2 Min. 3 Min. 5 Min. 10 Min.	When battery voltage threshold is detected When 2 minutes left in battery capacity When 3 minutes left in battery capacity When 5 minutes left in battery capacity When 10 minutes left in battery capacity	*
	BATT TST Length	Battery test time	Set duration to perform battery test.	2 Min. 5 Min. 10 Min. 20 Min.	Run for 2 minutes Run for 5 minutes Run for 10 minutes Run for 20 minutes	*	
	BATT TST Period	Battery test schedule	Set when (number of days) to run battery test automatically.	180 days 90 days 30 days None	Automatically every 180 days Automatically every 90 days Automatically every 30 days No automatic testing	*	
SET FUNCTION (function setting)	RUN TIM @PF	Operating period during outage	Set the time from when UPS starts backup to when it stops output.	BATT END 10 Sec. 30 Sec. 1 Min. 3 Min. 5 Min. 10 Min.	Until end of battery discharge Stop output after 10 seconds Stop output after 30 seconds Stop output after 1 minute Stop output after 3 minutes Stop output after 5 minutes Stop output after 10 minutes	*	
	RING Output	Ring operation	Set whether to output RING signal during UPS startup.	Output None	Output Do not output	*	
	Out Vol Adj.	Output voltage adjustment	Set adjustment for rated voltage set in 3.1. Each increment of adjustment is about 1V	-3 -2 -1 0 +1 +2 +3	Minus 3 increments Minus 2 increments Minus 1 increment No adjustment Plus 1 increment Plus 2 increments Plus 3 increments	*	
SET SYSTEM (system setting)	DATE/TIME	Date/Time	Set date and time for UPS.	DATE YY/MM/DD TIME HH:MM:SS	Date YY/MM/DD Time HH/MM/SS		
	ChA Total Unit#	Number of units in ChA system parallel connection	Set the number of UPS units connected in the UPS system	1 2 3 4 5 6 7 8	1 unit 2 units connected 3 units connected 4 units connected 5 units connected 6 units connected 7 units connected 8 units connected	Differs depending on UPS model	
	ChB Total Unit#	Number of units in ChB system parallel connection	Do not change anything here.	1 2 3 4 5 6 7 8	Do not change anything here.	*	
	Redundancy	UPS operation system	Redundant operation, or single machine/parallel operation	N+1 None	Redundant operation Single machine/parallel operation	*	
	INPUT Phases	Input phase ★	Specify input phase of UPS	Single 3Ph/4W *1	Single phase, 2 wires 3 phases, 4 wires	*	
SET DEFAULT (initialization)	SET DEFAULT	Reset to factory default setting	—	—	—	—	

★: Settings that require restarting UPS *1: Do not set values to these settings.

4. CONTROL

Home menu	Operation		Displayed item		Displayed content					
	Display	Description	Display	Description	Display	Description	Result	Description		
CONTROL (UPS operation)	BATTERY TEST	Run battery test	Start	Start	[SELECT] = OK	OK to start	Control NG	Operation canceled		
					[BACK] = Cancel	Cancel	Control OK	Normal termination		
			STATUS	Test status	Test Condition	Test status			Possible	Test can start
									Impossible	Test cannot start
									Testing	Test in progress
					Last Test Time	Date of last test			YY/MM/DD 00:00	YY/MM/DD HH:MM
			Last Result	Result of last test					BATTST:OK	Normal
									BATTST:NG	Error
									BATTST: No Result	No previous result
									BATTST:Error	Error
					BATTST:Suspended	Aborted				
	INV ON	Start UPS	[SELECT] = OK	ON	Control NG	Operation canceled	Control OK	Normal termination		
			[BACK] = Cancel	Cancel						
	INV OFF	Stop UPS	[SELECT] = OK	OFF	Control NG	Operation canceled	Control OK	Normal termination		
			[BACK] = Cancel	Cancel						
BYPASS	Switch to bypass operation	[SELECT] = OK	Switch	Control NG	Operation canceled	Control OK	Normal termination			
		[BACK] = Cancel	Cancel							

5. MAINTENANCE (for service technician)

Home menu	Operations group	Displayed item		Item					
		Display	Description						
MAINTENANCE (maintenance)	MAINTENANCE SYSTEM (maintenance of UPS system)	FAIL HIST	Malfunction history	HIST # (1~4)	Malfunction history display: up to 4 can be saved.				
		OPE. HIST	Operation history	HIST # (1~8)	Operation history display: up to 8 can be saved.				
		INTERNAL INFO.	Battery information	BATTERY INFO.	Battery information	BATTERY INFO.	Battery information	Power Failure Times	Number of outages
								Battery Life Years	Battery life
								INV OPE. Time Hours	Accumulated time on UPS operation
								Backup OPE. Time Sec.	Accumulated time on battery operation
								Last Test Time YY/MM/DD HH:MM	Date of last test
								Last Result *1	Result of last test
		RESET BATT INFO.	Reset battery information						
		INTERNAL INFO.	Battery information	BATT. CAPA	Set backup time	Values		5Min.	5 minutes
	10Min.							10 minutes	
	15Min.							15 minutes	
	25Min.							25 minutes	
	30Min.							30 minutes	
	35Min.							35 minutes	
	45Min.							45 minutes	
	60Min.							60 minutes	
	120Min.							120 minutes	
	180Min.							180 minutes	
	360Min.	360 minutes							
BATT. Life	Set battery life	Values	5Years	5 years (default)					
			10Years	10 years					
			13Years	13 years					
Unit INFO.	System information	UPS Model	UPS model name	Rated voltage	Rated input voltage				
		ROM Ver.	Program version	Pow Dist Num	Number of output systems				
		Run Time	Rated backup time	Always Out	Whether to have constant output				
		Out Capa	Rated capacity	Serial ID	Serial number				
		Input Phases	Number of input phases	P3-LCD Ver.	LCD program version				
		Output Phases	Number of output phases						
		UPS Model	UPS model name	Rated Voltage	Rated Input Voltage				
		ROM Ver.	Program version	Pow Dist Num	Number of output systems				
		Run Time	Rated backup time	Always Out	Whether to have constant output				
		Out Capa	Rated capacity	Serial ID	Serial number				
Input Phases	Number of input phases	P3-LCD Ver.	LCD program version						
Output Phases	Number of output phases								
MAINTENANCE UNIT1 UNIT8 (maintenance UPS unit 1 UPS unit 8)	INTERNAL INFO.	Battery information	BATTERY INFO.	Battery information	BATTERY INFO.	Battery information	Power Failure Times	Number of outages	
							Battery Life Years	Battery life	
	INV OPE. Time Hours	Accumulated time on UPS operation							
	Backup OPE. Time Sec.	Accumulated time on battery operation							
	Last Test Time YY/MM/DD HH:MM	Date of last test							
	Last Result *1	Result of last test							
	RESET BATT INFO.	Reset battery information							
	Unit INFO.	System information	UPS Model	UPS model name	Rated Voltage	Rated Input Voltage			
ROM Ver.			Program version	Pow Dist Num	Number of output systems				
Run Time			Rated backup time	Always Out	Whether to have constant output				
Out Capa			Rated capacity	Serial ID	Serial number				
Input Phases			Number of input phases	P3-LCD Ver.	LCD program version				
Output Phases			Number of output phases						
STATUS	Unit state display	Same as "1.STATUS"							
MEASUREMENT	Unit measurement display	Vbatt = V	Battery voltage	Vinv = V	Inverter voltage				
		Vchg = V	Charger voltage	Iinv = A	Inverter current				
		Ichg = A	Charger current	Vbus = V	Bus (BUS) voltage				
		Tamb = °C	Ambient temperature						

*1. The "Last Result" item in the "MAINTENANCE" menu is same as the "Last Result" item in the "CONTROL" menu.

§7. Status Description

The following table lists details about UPS states that appear on the LCD screen in the “STATUS” home menu. If you cannot resolve the problem when the UPS malfunctions, contact your supplier or SANYO DENKI.

UPS mode		State display		
Display	Description	Display	Description	Details and solution
STANDBY	Standby	Output Not Sync	Asynchronous operation	Power supply is asynchronous with input power source. Switching to bypass operation is instant cutoff switching.
ONLINE	Online	Input Freq Err	Input frequency error	The input power source exceeds the acceptable frequency range. If it occurs during normal operation, power supply automatically switches to battery. If this problem occurs frequently, check the input power source and the UPS frequency setting.
BYPASS	During bypass operation	Input Vol Hi	High input voltage	The input power source exceeds the acceptable voltage range. If it occurs during normal operation, power supply automatically switches to battery. If this problem occurs frequently, check the input power source and the UPS frequency setting.
BATTERY	During battery operation	Input Vol Low	Low input voltage	Instant disconnection of input power source is detected. If it occurs during normal operation, power supply automatically switches to battery. If this problem occurs frequently, check the input power source and the UPS frequency setting.
BATT TEST	During battery testing	Input Error	Input error	Instant disconnection of input power source is detected. If it occurs during normal operation, power supply automatically switches to battery. If this problem occurs frequently, check the input power source and the UPS frequency setting.
SYS FAILURE	During system malfunction	INV Vol Hi	High inverter voltage (serious malfunction)	Inverter output voltage error is detected.
		INV Vol Low	Low inverter voltage (serious malfunction)	UPS is malfunctioning. Contact your supplier or SANYO DENKI.
		INV Vol Error	Inverter voltage detection circuit error (serious malfunction)	UPS is malfunctioning. Contact your supplier or SANYO DENKI.
		Output Stop (HV)	Bypass output stopped (excessive voltage)	Power supply stops because input over voltage is detected during bypass operation.
		OverLoad	Overload	There are a lot of load devices connected to the UPS to exceed the UPS rated capacity. Reduce the number of load devices.
		Vo= V Fo= Hz	Output voltage, output frequency	Output voltage, output frequency
		Vi= V Fi= Hz	Input voltage, input frequency	Input voltage, input frequency
		LF= % CHG= % *	Load factor %, Charging rate %	Load factor %, Charging rate %
		LF= % Tim= m *	Load factor %, Charging duration minutes	Load factor %, Charging duration minutes
		Byp Fuse Error	Bypass fuse error	There are a lot of load devices connected to the UPS to exceed the UPS rated capacity. As a result, the [MAIN MCCB] trips. Reduce the number of load devices.
		Bypass SW ON	Bypass switch ON	The forced bypass switch [Forced Bypass] is set to “Bypass”.
		Req To Restart	Restart is necessary.	Values for settings are changed but they require restart of the UPS before their changes take effect. Therefore, see §3.23 “Restarting UPS” and then restart the UPS.
		Remote	Battery test by remote operation in progress	Battery test is in progress by remote operation of power management software.
		Remote OFF	Operation stops due to remote OFF.	Inverter startup operation is canceled because remote OFF signal is input.
		EPO ON	Operation stopping due to EPO.	Inverter startup operation is canceled because EPO signal is input.
		Batt Life End	End of battery life	The battery life has come to an end. Replace the battery.
		Batt Life Warn	Battery life end warning	The battery will last for 6 more months. Prepare to replace the battery.
		Batt Vol Error	Battery voltage error	No battery pack is connected. Make sure a battery pack is installed.
		Batt Vol End	End of battery discharge	Battery discharge has ended.
		Batt Vol Low	Low battery voltage	Battery voltage is low.
		CHG Error	Charger error (serious malfunction)	UPS is malfunctioning. Contact your supplier or SANYO DENKI.
		CONV Error	Converter error (serious malfunction)	UPS is malfunctioning. Contact your supplier or SANYO DENKI.
		FIN Temp Error	Fin temperature error (serious malfunction)	UPS is malfunctioning. Contact your supplier or SANYO DENKI.
DSP Error	Controller error (serious malfunction)	UPS is malfunctioning. Contact your supplier or SANYO DENKI.		
BUS Error	DC voltage error (serious malfunction)	UPS is malfunctioning. Contact your supplier or SANYO DENKI.		
AUX2 Error	Auxiliary power error (minor malfunction)	UPS is malfunctioning. Contact your supplier or SANYO DENKI.		
BF Circuit Error	Back feed prevention circuit error (serious malfunction)	UPS is malfunctioning. Contact your supplier or SANYO DENKI.		
Total Unit# Err	Total number of units error (serious malfunction)	The number of UPS units set in §3.19 is different from the actual number of UPS units operating. Check the setting and the actual number of UPS units.		
LCD Error	LCD panel error	The LCD panel is malfunctioning. Contact your supplier or SANYO DENKI.		
Minor Error	Minor malfunction	Contact your supplier or SANYO DENKI.		
Fatal Error	Serious malfunction	UPS is malfunctioning. Contact your supplier or SANYO DENKI.		
FT Disabled	Redundant operation not allowed	In §3.20, if the operation system is set to “N+1”: there is a lot of load capacity connected to the UPS so that parallel redundant operation is not possible. Reduce the number of connected load devices.		
Check Unit Error	Device error exists and checking is required.	There may be communication error between units. Check the cable connecting the units.		

* Refer to §8 “Notes on UPS Measurements Information.”

§8. Notes on UPS Measurements Information

About the Battery Charge Rate Indication

- (1) Although the batteries in the UPS have been charged when shipping the UPS from factory, the battery charging rate “ChgRate = %” is indicated as “0%” if you operate the LCD panel to display it at initial startup of the UPS. Since the battery charging rate will increase according to operating time of the UPS, see the item “Charging UPS” in the *A11J Instruction Manual* to operate the UPS.
The operating time of which the battery charging rate becomes 100% differs depending on the configuration of the connected battery.
- (2) If the UPS is stopped and then restarted, even when the UPS is sufficiently charged, the battery charging rate may be indicated as “80%” or “90%.” This occurs due to the influence of operating conditions such as ambient temperature, and the battery charging rate will be indicated correctly if the UPS is operated for about 1 to 2 hours.
- (3) If the UPS is operated when the batteries are not connected properly, the battery charging rate “ChgRate = %” may not be indicated correctly. In such a state, even if the batteries are reconnected and the UPS is operated again, the correct value will not be displayed immediately. If this happens, the correct value will be indicated if the UPS is operated normally for at least 12 hours. However, the operating time of which the battery charging rate will be correctly indicated differs depending on the specifications of the UPS (configuration of the battery).
- (4) The value indicated by “ChgRate = %” is only an approximation. It may differ from the actual charge rate.

About the Battery Retention Time Indication

- (1) The battery retention time “RunTm = Min.” may not be displayed accurately if the load factor is 30% or less.
- (2) This battery retention time “RunTm = Min.” is only an approximation. It may differ from the actual backup time.

About the Load Factor Indication

- (1) The load factor value “LF = %” displayed by viewing UPS measurements is same even when either setting value (“N+1” or “None”) is set in §3.20 “Setting Operation System.”
Do not use the load devices in excess of the maximum load factor shown in the table below.
When setting to “N+1”, if you use the load devices in excess of the maximum load factor, the UPS can not perform the parallel redundant operation. Moreover the output power supply of some UPS model may stop. If the setting is “N+1”, and the load devices in excess of the maximum load factor, “FI Disabled” message is shown on the LCD screen. In this case, reduce the load devices connected to the UPS.

Maximum Load Factor by the setting value of Operation System

UPS	Operation System setting	Maximum Load Factor
A11J103	None	100 %
	N+1	50 %
A11J153	None	100 %
	N+1	65 %
A11J203	None	100 %
	N+1	75 %
A11J103N	None	(Do not set values to these settings.)
	N+1	65 %